

Lesson 03 Demo 05

Setting Up a Web Server on an EC2 Instance

Objective: To set up a web server on an EC2 instance, making it accessible via its public

IPv4 address

Tools required: AWS Management Console

Prerequisites: NA

Steps to be followed:


1. Create a VPC, a subnet, and an internet gateway

2. Create route tables

3. Create an EC2 web server instance


Step 1: Create a VPC, a subnet, and an internet gateway

1.1 Navigate to the AWS console home dashboard, search for, and click on VPC






1.2 In the VPC dashboard, click on Create VPC





1.3 Select the **VPC only** option, add a name tag as **my-subnets**, and set the IPv4 CIDR to **10.0.0.0/24**






1.4 Click on Create VPC








1.5 Navigate to **Subnets** and click **Create subnet** as shown:




1.6 Select the previously created **VPC**, name the subnet as **my-subnets**, add an **IPv4 subnet CIDR block** for the subnet, such as **10.0.0.0/24**, and click on **Create subnet**








1.7 Navigate to the Internet gateways, and click on Create internet gateway






1.8 Add a name as IG-4, and click on Create internet gateway




1.9 Select the created internet gateway, click on **Actions**, and select the **Attach to VPC** option






1.10 Select the Available VPCs, and click on Attach internet gateway




Step 2: Create route tables

2.1 Navigate to Route tables, and click on Create route table






2.2 Name the route table as route04, select the VPC, and click on Create route table




2.3 Click on Edit routes






2.4 Click on Add route




2.5 Add the destination value as **0.0.0.0/0**, set the target as **Internet Gateway**, select the previously created internet gateway, and click on **Save changes**






2.6 Click on Actions and select Edit subnet associations




2.7 Select the subnet and click on Save associations






Step 3: Create an EC2 web server instance

3.1 Navigate to the AWS console home dashboard, search for and click on EC2 as shown:




You will see the following interface:






3.2 Click on Instances on the left pane




3.3 Click on Launch instances as shown:






3.4 Provide the instance name, such as my web instances




3.5 Select Amazon Linux as the OS image







3.6 Choose t2.micro as the instance type




3.7 Click on **Create new key pair**, add **my web instances** as key pair name, select the required private key file format, and click on **Create key pair**








3.8 Click on the Allow HTTP traffic from the internet checkbox as shown:






3.9 Click on Edit




3.10 Select the previously created VPC and subnet, and enable Auto-assign Public IP






3.11 Click on Advanced details




3.12 Add the following code in **User data**, and click on **Launch instance**:

#!/bin/bash
yum update -y
yum install -y httpd
systemctl start httpd
systemctl enable httpd
echo '<h1>VM to DB Connect</h1>' > /var/www/html/index.html






You will see the following interface:



The EC2 web instance has been created successfully.

3.13 Select the instance and copy the public IPv4 address





3.14 Open a new browser tab, paste the public IPv4 address, and use port 80 to access the web server:

3.82.196.10:80



By following these steps, you have successfully set up a web server on an EC2 instance and made it accessible via its public IPv4 address.